

Welte Nine Rank Theater Organ

PEDAL

16 Bourdon
 8 Diaphonic Diapason
 8 Tibia Clausa
 8 Clarinet
 8 Cello
 8 Flute
 8 Solo to Pedal

Tremulants

Main
 Solo
 Vox
 Tibia

Swell Shoes

Main
 Solo

ACCOMP

8 Harmonic Trumpet
 8 Horn Diapason
 8 Tibia Clausa
 8 Clarinet
 8 VDO
 8 Viol Celeste
 8 Concert Flute
 8 Vox Humana
 4 Flute
 4 Vox Humana
 2-2/3 Twelfth
 2 Piccolo
 Harp

SOLO

16 Tibia Clausa (Ten C)
 16 Bourdon
 16 Vox Humana (Ten C)
 8 Harmonic Trumpet
 8 Horn Diapason
 8 Tibia Clausa
 8 Clarinet
 8 VDO
 8 Viol Celeste
 8 Muted Viol
 8 Concert Flute
 8 Vox Humana
 5-1/3 Tibia Clausa
 4 Harmonic Clarion

4 Octave
 4 Tibia Clausa
 4 Flute
 2-2/3 Tibia
 2-2/3 Twelfth
 2 Tibia
 2 Fifteenth
 2 Piccolo
 1-3/5 Tibia
 1-3/5 Tierce
 1 Tibia
 Harp
 16 Solo Sub Octave
 4 Solo Octave

Solo percussions

Chimes


Wurlitzer Console



Stops Available

Pedal- 5
 Accomp- 13
 Solo- 17


Main Division



Tibia, VDO, VDO Cel, Clarinet

VOX not shown

Solo Division



Flute, Muted String, Diapason, Trumpet